



## Instructions & Grooming Guide

[www.furbuster.com](http://www.furbuster.com)

**Read before using the FurBuster® Professional De-shedding Tool. This tool is intended to be used for grooming as directed below and on "shedding" animals ONLY. If you are not certain if your pet is a shedding breed, please consult your veterinarian.**

Change blades with just the push of a button!



Look for FurBuster® Replacement Blades sold separately.

Various sizes available for all grooming needs!



**For Best Results:** Shampoo and dry your pet's coat before using the de-shedding tool. Make sure the coat is COMPLETELY dry before grooming. Be sure to select a work area that is easy to sweep or vacuum.

**Before You Start:** Perform a complete inspection of your pet for cuts, bruises, abrasions, sores or skin conditions. Your pet's coat can hide these skin conditions; please be sure to inspect your pet closely. DO NOT USE the FurBuster® Professional De-shedding Tool if any of these skin conditions exist. Take your pet to a veterinarian for professional treatment.

### Directions for Use

- Before using FurBuster® De-Shedding Tool on your pet, inspect and remove any tangles and/or matting from your pet's coat with proper grooming tools.
- Always start from the head and move down the body and comb with the blade and teeth angled toward the coat. Do not use on or around sensitive areas like ears, legs and genitals.
- Pull tool slowly and gently with long, smooth strokes, in the direction of hair growth. Stroke up and away from pet's skin. Do not use repeated strokes in the same area and do not apply too much pressure on the tool as you comb. Rough combing can lead to skin irritation and discomfort. Pets with sensitive skin may suffer brush burns even with light combing. If you notice any redness or irritation, stop using the tool.
- When finished, always store the tool and any replacement blades in a safe place, out of reach of children.

### Directions for Blade Cleaning & Storage

- Remove remaining hair from blade and place blade cover on to protect blade teeth.
- The stainless steel blade can be removed from tool, and rinsed with water and/or alcohol, but should be dried immediately to maintain sharpness of blade teeth.

### Directions for Blade Replacement

- For professional groomers and pet owners with pets of different sizes and breeds, the FurBuster® Professional De-shedding Tool is designed with interchangeable/ replaceable blades that snap easily and securely into the comfortable universal handle.
- Place blade cover over the blade edge, press the center button on the head of the tool and pull blade from tool.
- To insert the blade, simply slide the covered blade into the tool until it snaps into place. Confirm that the blade is securely in place. All FurBuster® replacement blades are uniquely designed to fit into the universal tool handle.

Product design is a TM and © 2007 Munchkin, Inc. Munchkin, Bamboo and FurBuster are registered trademarks of Munchkin, Inc. 16689 Schoenborn Street, North Hills, CA 91343. Made in China.